# Hustler<sup>®</sup> Raptor<sup>®</sup> Flip-Up Operator's Manual





200 South Ridge Road Hesston, Kansas 67062

## **Manual version**

Original Instructions in English

## Hustler® Turf Equipment Authorized Representative

Southern Machinery LTD Downings South, Prosperous NAAS Co. Kildare IRL ---Telephone: +353 45 86 0031 www.southernmachinery.ie Email: gtutty@eircom.net

## **Excel Industries, Inc.**

## Manufacturer of Hustler® Turf Equipment

200 South Ridge Road Hesston, Kansas 67062 Telephone: (620) 327-4911 FAX: (620) 327-2828

## **Table of Contents**

Mower Blade Options4-Seat Adjustment4-Steering Control Lever Adjustment4-	7
Troubleshooting	1
Storage	1
Technical Specifications	1

## **GENERAL INFORMATION**

This manual applies to the following Hustler<sup>®</sup> Turf Equipment product lines:

#### Hustler® Raptor® Flip-Up

#### To the New Owner

Hustler<sup>®</sup> Raptor<sup>®</sup> Flip\_Up mowers are designed to be used as riding lawn mowers, they must be used for mowing purposes only.

Hustler<sup>®</sup> mower owners and operators **must read** this manual carefully. It contains operation and maintenance information that will help you achieve years of dependable service.

The Engine Owner's Manual, included in the owner's packet, contains engine information that will not be repeated in this manual.

The **owner's responsibilities** include, but are not limited to, making certain that the operators and mechanics:

- read and understand the engine owner's manual before attempting to operate or repair the engine.
- read and understand the mower's operator manual and all decals before operating this machine.
- are qualified and physically able individuals, properly trained in the operation and maintenance of this equipment. Before they are allowed to operate or maintain this machine, they **must** be familiar with its safe operation, operator controls, and decals.
- know they are responsible for their own safety as well as the safety of other persons within the vicinity.
   Remember, the operator is responsible for accidents or hazards occurring to other people or their property.

**IMPORTANT:** As the owner/operator you can prevent accidents. You are responsible for accidents or injuries occurring to yourself, other people or property.

Never let children or untrained people operate or service the equipment. Local regulations may restrict the age of the operator.

For more detailed maintenance and adjustment information refer to the proper *General Service Manual* for your machine. Refer to the *Product Literature* section of this manual for information on how to obtain this manual.

#### Using this Manual

606224CE

**IMPORTANT:** Any maintenance operation that requires the removal of safety covers **must** be performed by a trained service technician.

This manual contains general operation information as well as basic adjustment and maintenance information. Since operating conditions vary considerably, all conditions cannot be addressed individually. Through training and experience, operators should develop safe operating practices suitable to most conditions.

Directions used in this manual, for example RIGHT or LEFT, refer to directions when in the operator position and facing forward, unless otherwise stated.

Though current at the time of printing, photographs and illustrations shown may vary slightly from your mower due to subsequent production changes. Hustler<sup>®</sup> Turf Equipment, Inc. reserves the right to redesign and change the machine as deemed necessary, without notification. If a change has been made to your machine which is not reflected in this manual, contact your Hustler<sup>®</sup> Dealer for current information.

## Warranty Registration

To activate your warranty policy the mower **must** be registered, by your Dealer, with the Manufacturer of Hustler<sup>®</sup> Turf Equipment within **ten (10) days** following the date of purchase. It is recommended that you contact your Dealer to make sure the mower is registered.

**IMPORTANT:** The mower and any attachment that displays a model and serial identification number plate **must** be registered with Excel Industries, Inc., manufacturer of Hustler® Turf Equipment, Inc ("Manufacturer").

**IMPORTANT:** Any unauthorized modification, alteration, or use of non-approved attachments voids the warranty and releases Manufacturer from any liability arising from subsequent use of this equipment. **Do not** use or operate any attachment not approved by Hustler<sup>®</sup> Turf Equipment, Inc.

**IMPORTANT:** Damage caused by unauthorized replacement parts is not covered by this warranty. Manufacturer expressly excludes liability for defects or damage caused by such 'unauthorized' articles or service.

#### **Model and Serial Number**

The serial identification plate, located on the left side of the seat support, contains the mower's model and serial numbers.

These numbers are required when the unit is registered with Hustler<sup>®</sup> Turf Equipment. They will also assure you of the correct service parts when replacement becomes necessary. Shown below is an example of a serial identification plate and how to interpret it.




Figure 1-1

## **Parts and Service**

Use original Hustler<sup>®</sup> replacement parts, or parts that are equivalent in overall performance, that are available from your local Hustler<sup>®</sup> Dealer. For prompt, efficient service, always provide the following information when ordering parts:

- 1. Correct part description.
- 2. Correct part number.
- 3. Correct model number.
- **4.** Correct serial number.

All arrangements for warranty repair and service must be handled through an authorized Hustler<sup>®</sup> Dealer.

## **Product Literature**

If you would like to view or print a copy of this manual go online to www.hustlerturf.com.

Contact your local Hustler<sup>®</sup> Dealer if you require another engine owner's manual.

## SAFETY PRECAUTIONS



This safety alert symbol is used to call attention to a message intended to provide a reasonable degree of **PERSONAL SAFETY** for operators and other persons during the normal operation and servicing of this equipment.

A DANGER A	– denotes immediate hazards which <b>WILL</b> result in severe personal injury or death.
A WARNING A	<ul> <li>denotes a hazard or unsafe practice which COULD result in severe personal injury or death.</li> </ul>

This manual uses two other words to highlight information:

- A. IMPORTANT calls attention to special mechanical information.
- **B.** NOTE emphasizes general information worthy of special attention.

The owner's responsibilities include, but are not limited to,

- making certain that the operators and mechanics read and understand this manual and all decals before operating this machine.
- making certain that before the operators and mechanics are allowed to operate or maintain this machine, they **must** be familiar with its safe operation, operator controls, and decals.
- ensuring that the operators and mechanics know they are responsible for their own safety as well as the safety of other persons within the vicinity. **Remember**, the operator is responsible for accidents or hazards occurring to other people or their property.

Improper use, adjustment, or maintenance by the operator, mechanic or owner can result in injury or death. Reduce the potential for injuries by following these safety instructions. Pay close attention to the safety alert symbol " $\blacktriangle$ " and the instructions that follow it. Failure to comply with these instructions may result in personal injury or death.

Incorrect usage of this equipment may result in severe injury or death. Personnel operating and maintaining it should be trained in its proper use. They should read this manual completely and thoroughly before attempting to set-up, operate, adjust, or service this equipment.

## **Safe Operating Practices**

This product is capable of amputating hands and feet and throwing objects. Always follow all safety instructions to avoid serious injury or death.

▲ Never allow persons to operate this mower without proper instruction or allow children to operate the mower. Allow only responsible adults who are familiar with these instructions to operate this mower.

## **Safe Operation**

- ▲ Evaluate the terrain to determine what accessories and attachments are needed to properly and safely perform the job. Only use accessories and attachments approved by the manufacturer.
  - Do not use any unauthorized attachment or modify the mower.
  - Follow the manufacturer's recommendation for wheel weights or counterweights.
  - If any attachment or additional weight is mounted on the rear of the unit, any rapid movement of the control levers in either direction could result in a reaction of the mower that can cause serious injury.
- ▲ **Do not** use a catcher on any mower equipped with Flex Forks<sup>®</sup>.
- ▲ Always be alert and inspect area to be mowed for hazards such as rocks, metal objects and other debris which may be thrown or entangled by mower blades. Remove these objects before mowing. Watch out for holes or deep depressions.
- Always operate mower in daylight or with adequate working lights.
- Never operate the mower when there is a risk for lightning.

## **Personal Safety**

- ▲ Always wear long pants and safety shoes with slipresistant soles when operating this mower.
  - Do not wear sandals, tennis shoes, sneakers, shorts or any type of loose fitting clothing as they may get tangled in moving parts.
  - Do not wear a towel from the waist, or use a towel as a headband or neck wrap.
  - Long hair or jewelry may get tangled in moving parts.

REV D

- ▲ Always wear adequate ear protection, such as earplugs. Prolonged exposure to loud noise can cause impairment or loss of hearing.
  - Do not wear radios or music headphones while operating this mower. Safe operation requires your full attention.
- ▲ Always wear safety goggles or safety glasses with side shields when operating this mower.
- ▲ Do not operate the mower if you are fatigued, sick or while under the influence of alcohol or drugs, if you are pregnant or under 18 years old.
- ▲ Poor posture or operating the mower for extended periods of time may lead to fatigue or injury, resulting in loss of mower control. Occasionally, stop the mower and get off the seat to stretch and relax.
- ▲ Always be aware of abnormal mower vibration. Prolonged exposure to excessive mower vibration can lead to discomfort, low-back morbidity, neurological, osteo-articular and vascular disorders, and/or trauma to the spine.
- ▲ Data indicates that operators aged 60 years and above are involved in a large percentage of riding mowerrelated injuries. These operators should evaluate their ability to operate the mower safely enough to protect themselves and others from serious injury.

#### Operation

- ▲ Never leave a running mower unattended. Before leaving the operator's seat for any reason, including emptying the catcher or unclogging the chute:
  - · Always stop on level ground.
  - Disengage the deck clutch.
  - Place the steering control levers in the park brake position.
  - Stop the engine.
  - Remove the ignition key.
  - Wait for the engine and all moving parts to come to a complete stop.
- ▲ Always inspect mower for damage after striking a foreign object. If damage is found, repair mower immediately.
- ▲ Always remain seated while operating the mower. Only start the engine from the operator's position.
- ▲ Turn off the mower blades when not mowing.
- ▲ Always keep safety shields and covers in place, except for servicing.
  - Never operate the machine with the floor plate pulley cover removed.
- ▲ Never operate the mower deck with the discharge chute damaged, altered, removed, or in the raised position, except when the entire grass catcher attachment or mulching system is being used.

- Always keep clear of the mower blades and attachments during their operation.
  - Never put hands or feet under any part of the mower while it is running.
- ▲ Stop the engine before removing the grass catcher or unclogging the discharge chute. Never clear the discharge chute with the engine running. Turn off the engine and be sure the blades have stopped before cleaning. Use a stick to clear a plugged discharge area. Never use your hand!
- ▲ Follow daily and weekly checklists, making sure hoses are tightly secured and bolts are tightened.
  - · Never operate a poorly maintained mower.
- ▲ Clean flammable material from mower. Prevent fires by keeping the engine compartment, top of the deck, exhaust area, battery, fuel line, fuel tank and operator's station clean of accumulated trash, grass clippings, and other debris. Always clean up spilled fuel and oil.
- ▲ Prevent fires by keeping the engine and exhaust areas clear of grass clippings and other debris. Do not back mower into flammable materials.
  - Allow the mower, especially the engine, to cool in a well ventilated area before storing inside a building or other enclosure.
- ▲ Do not change the engine governor setting or over speed the engine. Operating the engine at excessive speed may increase the hazard of personal injury.
- Rapid movement of the steering control levers in either direction could result in a reaction of the mower that can cause serious injury.
  - Never push forward suddenly on your steering control levers while the mower is in rearward motion because mower may tip backwards.
  - Never pull back suddenly on your steering control levers while the mower is in forward motion.
- ▲ Always be aware of what is behind the mower before backing up. Never mow in reverse. Always look down and behind before and while backing up.
  - If mowing in reverse is unavoidable, push forward slowly on the steering control levers and avoid sudden movement.
- Slow down before turning.
- Never attempt high speed maneuvering, especially in crowded or congested areas.
- ▲ Always maintain a safe distance from people and pets when mowing. Always stop mower if someone enters the area.
- ▲ Never carry passengers.
- ▲ Never direct discharged material toward anyone. Avoid discharging material against a wall or obstruction. Material may ricochet back toward the operator. Always disengage the mower blades and wait for them to stop before crossing gravel drives, walks or roads.

- ▲ Always observe traffic laws while driving mower from one location to another. Watch for traffic when operating near or crossing roadways.
  - Use care when approaching blind corners, shrubs, trees, or other objects that may obscure your vision.

#### Using a Ramp

- ▲ Exercise extreme caution when loading and unloading a mower onto a truck or trailer with a ramp.
- ▲ Use only a single, full width ramp; do not use individual ramps for each side of the unit. Having a full width ramp provides a surface for the mower frame to contact if the unit starts to tip backwards. It also reduces the risk of a wheel going off and the mower tipping over.
- ▲ Do not exceed a 15 degree angle between the ramp and the ground or between the ramp and the trailer or truck.
- Avoid sudden acceleration when on a ramp.

## **Slope Operation**

Slopes are a major factor in loss-of-control and tip-over accidents, which can result in severe injury or death. All slopes require extra caution. If you cannot back the mower up the slope or if you feel uneasy on the slope; do not mow it. REMINDER: Only operate on slopes of 15 degrees or less.

- ▲ Use extreme caution when operating on slopes.
  - Be extremely careful changing directions on a slope. Slow down.
  - Do not operate where the mower could slip or tip.
  - Turn slowly
  - Turn on the most level part of the slope
  - To maximize traction, it is better to turn the front of the mower uphill, rather than downhill. If drive tires lose traction, steering control is lost which could cause serious injury or death.
  - If it becomes necessary to turn downhill, turn slowly and gradually, if possible.
- ▲ Watch for holes, ruts, bumps, rocks or other hidden objects. Uneven terrain could overturn the mower. Tall grass can hide obstacles.
- A Remove obstacles such as rocks, tree limbs, etc.
- ▲ Keep all movement on slopes slow and gradual. Do not make sudden changes in speed or direction.
- ▲ Avoid starting and stopping on a slope. If tires lose traction, disengage the mower blades and proceed slowly straight down the slope.
- ▲ Mow a safe distance (minimum of 10 feet) away from drop-offs, retaining walls, drainage ditches, embankments, water, and other types of hazards to avoid a wheel dropping over the edge or to avoid the ground from breaking away. This will reduce the risk of the

mower suddenly rolling over causing serious injury or death.

- ▲ Use a walk behind, push mower or hand-held trimmer on slopes and near drop-offs, retaining walls, drainage ditches, embankments and water to avoid mower rollover and serious injury or death.
- ▲ Do not mow on wet grass. Slippery conditions reduce traction which could cause sliding and loss of steering control.
- ▲ Do not tow on slopes. The weight of the towed equipment may cause loss of traction and loss of steering control.
- ▲ Do not try to stabilize the mower by putting your foot on the ground.
- ▲ If the mower's tires lose traction when operating on slopes, disengage the blades, place the control levers in the park brake position, stop the engine, remove ignition switch key, and get help.
- ▲ Never make sudden starts, stops, turns, or reverse direction, especially when maneuvering on slopes. The steering is designed for sensitive response. Rapid movement of the control levers in either direction could result in a reaction of the mower that can cause serious injury.
- ▲ Never stop suddenly while backing down slopes. This action may result in a reaction of the mower that can cause serious physical injury.
- ▲ The Hustler<sup>®</sup> mower is capable of operating horizontally (traverse) on moderately steep slopes. When operating on slopes up to 15 degrees, be aware of any conditions that may cause the mower drive tires to lose traction resulting in a possible loss of control of the mower. An operator should not operate on a slope until he is thoroughly familiar with the equipment.

#### Do not operate on slopes greater than 15 degrees.

Refer to the *Slope Guide*, when determining the degree of slope to be mowed.

It is strongly recommended that the operator drive the mower off of the slope, using extreme caution, if any sign of loss of traction is detected. Wait until the condition that caused the problem is resolved before attempting to operate on the slope again.

Terrain conditions can affect traction resulting in possible loss of control of the mower. Some of the conditions to be aware of are:

- Wet terrain
- Depressions in the ground; i.e. holes, ruts, washouts
- Mounds of dirt
- Soil type; i.e. sand, loose dirt, gravel, clay
- Grass type, density, and height
- Extremely dry conditions of grass
- Tire pressure

The attachments mounted to the mower will also affect the way it handles on a slope. Be aware that each attachment's characteristics vary.

Another consideration to safe mowing on slopes is to be aware of what is located at the bottom of the slope. Extreme caution should be used when there is a hazard located at the bottom of the slope. Some examples are:

- Water; i.e. lake, river
- · Cliffs, retaining walls
- Roads, highways
- Buildings
- Rocks

These are just a few examples of situations when caution must be used when operating on a slope. There are many other possibilities too numerous to mention. Just remember to always exercise extreme caution when operating on any slope.

#### Children

Tragic accidents can occur if the operator is not alert to the presence of children. Children are often attracted to the mower and the mowing activity. Never assume that children will remain where you last saw them.

- ▲ Never leave the mower unattended with the ignition key in the switch, especially with children present.
- ▲ Children or bystanders may be injured if they attempt to move or to operate the mower while it is unattended. Always disengage the deck clutch, place the control levers in park brake position, stop the engine, and remove the ignition key when leaving the operator's seat.
- ▲ Keep children out of the mowing area and under the watchful care of a responsible adult other than the operator.
- ▲ Be alert and turn the mower off if children enter the area.
- Before and while backing, look behind and down for small children.
- ▲ Never carry children, even with the blades off. They may fall off and be seriously injured or interfere with safe mower operation. Children who have been given rides in the past may suddenly appear in the mowing area for another ride and be run over or backed over by the mower.
- ▲ Never allow children to operate the mower.
- Never allow children or others in or on towed equipment.
- ▲ Use care when approaching blind corners, shrubs, trees, the end of a fence or other objects that may obscure vision.

#### **Service Precautions**

- ▲ Unless specifically required, **DO NOT** have the engine running when servicing or making adjustments to the mower.
  - Park the mower on level ground.
  - Disengage the deck clutch.
  - Place the steering control levers in the park brake position.
  - Lower the deck.
  - Stop the engine.
  - · Remove the ignition key.
  - · Disconnect the negative battery cable.
  - Wait for all movement to stop before adjusting, cleaning or repairing.
  - Repairs or maintenance requiring engine power should be performed by trained maintenance personnel only.
  - To prevent carbon monoxide poisoning, operate the engine in a well ventilated area only.
  - Read and observe all safety warnings in this manual.
- Before working on or under the deck, make certain the engine cannot be accidentally started.
- Always keep belt covers on mower deck for safety as well as for cleanliness except when changing or checking the belt.
- ▲ Use a stick or similar instrument to clean under the mower making sure that no part of the body, especially arms and hands are under the mower.
- Always wear adequate eye protection when:
  - servicing the hydraulic system.
  - · servicing the battery.
  - grinding mower blades and removing accumulated debris.
- ▲ Never attempt to make any adjustments or repairs to the mower drive system, mower deck or any attachment while the mower engine is running or deck clutch is engaged. Repairs or maintenance requiring engine power should be performed by trained maintenance personnel only.
- Never work under the machine or attachment unless it is safely supported with jack stands.
  - Make certain machine is secure when it is raised and placed on the jack stands.
  - The jack stands should not allow the machine to move when the engine is running and the drive wheels are rotating.
  - Use only certified jack stands. Use only appropriate jack stands, with a minimum weight rating of 907 kg to block the unit up.
  - Use in pairs only.

- Follow the instructions supplied with the jack stands.
- ▲ Exercise caution when releasing spring tension from any of the belt idlers or when working with any of the deck lift components.
- ▲ Do not touch hot parts of machine.
- ▲ Keep nuts and bolts tight, especially the blade attachment bolts. Keep equipment in good working condition.
- ▲ Never tamper with safety devices. Check their proper operation regularly.
- ▲ Grass collection system components are subject to wear, damage and deterioration, which could expose moving parts or allow objects to be thrown. Frequently check components and replace with manufacturer's recommended parts, when necessary.
- ▲ Exercise caution when working under the deck as the mower blades are extremely sharp. Wrap the blade(s) or wear gloves and use extra caution when servicing them.
- ▲ Use original Hustler<sup>®</sup> replacement parts, or parts that are equivalent in overall performance, that are available from your local Hustler<sup>®</sup> Dealer.
  - The mower may not comply with the appropriate safety standards if aftermarket parts, accessories, or attachments are used.

#### Mower Blade Maintenance Precautions

- ▲ Never attempt to straighten a bent blade by heating, or weld a cracked or broken blade as the blade may break and cause serious injury. Replace worn or damaged blades.
- ▲ Never work with blades while engine is running or deck clutch switch is engaged (on).
- ▲ Always wear adequate eye protection when grinding mower blades.
- ▲ Mower blades are sharp and can cut. Wrap the blade(s) or wear gloves and use extra caution when servicing them.

## **Battery Service Precautions**

- ▲ Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. Wash hands after handling.
- ▲ Charge batteries in a well-ventilated open area, away from sparks and flames. Unplug charger before connecting or disconnecting from battery. Wear protective clothing and use insulated tools.
- Avoid skin and clothing contact with battery acid.
  - Always wear eye protection when checking the battery. Acid can cause serious injury to skin and eyes. If contact occurs, flush area with clean

water and call a physician immediately. Acid will also damage clothing.

- Do not drink the battery electrolyte.
- Do not allow open flame near the battery when charging.
- Hydrogen gas forms inside the battery. This gas is both toxic and flammable and may cause an explosion if exposed to flame. Always **disconnect** the negative (black) battery cable(s) before disconnecting the positive (red) cable(s). Always **connect** the positive (red) battery cable(s) before connecting the negative (black) cable(s).
- Do not overfill the battery.
- Electrolyte may overflow and damage paint, wiring or structure. When cleaning the battery, use soap and water. Be careful not to get soap and water into the battery. Clean the battery terminals with a solution of four parts water and one part baking soda when they become corroded.
- ▲ Shorts caused by battery terminals or metal tools touching metal mower components can cause sparks. Sparks can cause a battery gas explosion which will result in personal injury.
  - Prevent the battery terminals from touching any metal mower parts when removing or installing the battery.
  - Do not allow metal tools to short between the battery terminals and metal mower parts.
- ▲ Incorrect battery cable routing could cause damage to the mower and battery cables. This can cause sparks which can cause a battery gas explosion which will result in personal injury.
  - Always **disconnect** the negative (black) battery cable(s) before disconnecting the positive (red) cable(s).
  - Always **connect** the positive (red) battery cable(s) before connecting the negative (black) cable(s).

## **Fuel Handling Precautions**

- ▲ To avoid personal injury or property damage, use extreme care when handling gasoline. Gasoline is extremely flammable and the vapors are explosive.
  - A fire or explosion from gasoline can burn you and others and can damage property.
- ▲ Observe the usual gasoline handling precautions:
  - Do not smoke while refueling. Extinguish all cigarettes, cigars, pipes and other sources of ignition.
  - Do not remove fuel cap or fill tank with engine running or while engine is hot. Clean up any gasoline spills.
  - If gasoline is spilled, do not attempt to start the engine but move the machine away from the area of spillage and avoid creating any source of ignition until gasoline vapors have dissipated.

- Keep gasoline away from open flame or spark and store machine away from open flame or spark or pilot light such as on a water heater or appliances.
- Refuel outdoors. Never refuel or drain the gasoline from the machine indoors.
- Never attempt to start the engine when there is a strong odor of gasoline fumes present. Locate and correct the cause.
- Store gasoline in an approved container and keep it out of the reach of children. Never buy more than a 30-day supply of gasoline.
- Do not fill fuel containers inside a vehicle or on a truck or trailer bed with interior carpets or plastic truck bed liners. Always place gasoline containers on the ground away from your vehicle before filling.
- When practical, remove the machine from the truck or trailer and refuel the machine with its wheels on the ground. If this is not possible, then refuel such machine on the truck or trailer using a portable container and not a fuel dispenser nozzle. If a fuel dispenser nozzle must be used, keep the nozzle in contact with the rim of the fuel tank or container opening at all times until fueling is complete. Do not use a nozzle lock-open device.
- Never use gasoline for cleaning parts.
- Read and observe safety precautions elsewhere in this manual.
- Gasoline is harmful or fatal if swallowed.
- Avoid prolonged breathing of vapors.
  - Long-term exposure to vapors can cause serious injury and illness.
- ▲ Keep gasoline away from eyes and skin.
  - Keep face away from nozzle and fuel tank or fuel container opening.
  - If gasoline is spilled on clothing, change clothing immediately.

## Safety and Instructions Decals

The decals are designed to give the operator and mechanic brief daily operational and service information. Use these decals as an extension of this manual. Do not remove or obliterate the decals. Replace unreadable or missing decals. It is the **owner's responsibility** to make certain that the operators and mechanics read and understand all decals before operating this machine.

Specific safety warning decals are located on the equipment near the immediate areas of potential

hazards. Do not remove or obliterate these decals.

Replace them if they become non-readable.

WARNING

The following illustrations show the safety decals that are located on the mower. A brief explanation is shown to help the operator understand the decal's meaning.



• Read Operator's Manual and Safety Warning Decals before attempting to operate this machine.



- Do not smoke while refueling.
- Do not remove the fuel tank cap or fill tank with engine running or while the engine is hot.
- Allow the mower, especially the engine, to cool in a well ventilated area before storing inside a building or other enclosure.
- Store away from open flame or spark if there is fuel in tank.
- Clean up any gasoline spills.
- Do not refuel while in enclosed trailer or other enclosed areas.
- Maximum of 10% ethanol (E10) in fuel. Fuels with greater than 10% ethanol, (such as E15, E20 and E85) voids warranty. Fuels with greater than 10% ethanol are not approved for use and such use could cause equipment failure and pose a fire hazard.



Part Number 602041
Keep a safe distance from the machine.

WARNING: Hot surface!

EN



WARNING: Fire!

Part Number 601967

Clean flammable material from machine. Prevent fires by keeping engine compartment, top of deck, exhaust area, battery, fuel line, fuel tank and operator's station clean of accumulated trash, grass clippings, and other debris. Always clean up spilled fuel and oil.

#### WARNING: Thrown objects!

 Never operate the mower deck with side deflector damaged, altered, removed or in raised position, except when the entire grass catcher attachment or mulching system is being used.

	<u>*</u>
	<b>.</b>
ĪĖĨ↔Ť	مروندون دورویون


Part Number 604221

#### DANGER: Rotating blades, pulleys & belts

- Keep shields and covers in place while machine is in operation.
  Keep hands, feet and clothing
- away from rotating pulleys and belts.

#### Part Number 785139 & 785220

Park brake position Forward position






#### Top of Deck Clutch Switch Shown



- A. Deck clutch disengaged (OFF) position
- B. Deck clutch engaged (ON) position



#### WARNING: Read Operator's Manual and decals before attempting to operate this machine.



Part Number 605650

While raising the deck to the service position do not create a situation that allows the drive tires to rise off the ground. If the drive tires are raised off the ground it may cause the vehicle to move in an unexpected manner including, but not limited to, tipping or rolling. If the drive tires rise off the ground, stop and return the vehicle to the operating position.

**DANGER: Battery Hazards!** 



- Avoid skin contact with battery acid
- con- Do not overfill battery.
  - Electrolyte may overflow and damage paint, wiring or structure. When cleaning the battery, use soap and water. Be careful not to get soap and water into the battery. Use soda mixed in water to clean corrosion off the terminals.
  - Always wear eye protection when checking the battery, acid can cause serious injury to skin and eyes. If contact occurs, flush area with clean water and call physician immediately. Acid will also damage clothing.
- Do not allow open flame near the battery when charging.
- Hydrogen gas forms inside the battery. This gas is both toxic and flammable and may cause an explosion if exposed to flame. Always remove the negative ground first and replace it last.

#### Part Number 605685



Mower blade - Height adjustment


Part Number 789776CE



#### Part Number 794834CE



This label on your mower indicates that this model has been certified and is in compliance with European Directive 2000/14/EC.



- A. Fast
- B. Slow
- C. Mower blade engage/disengage switch
- D. Ignition switch insert key
- E. OFF
- F. ON
- G. Engine start position
- H. Wear ear protection, eye protection and safety shoes when operating this equipment.
- I. Read Operator's Manual before attempting to operate this machine.
- J. Before starting the engine:
  - Read Owner's Manual
  - Disengage mower blades
  - · Place control levers in park brake position

- **K.** For maximum electric clutch life engage at 1/2 3/4 throttle position.
- L. For maximum electric clutch life disengage at low throttle position.
- M. Service position
- N Operating position
- 0. Raise deck position
- P. Lower deck position
- Q. WARNING: Pinch point!
  - Keep a safe distance from machine.
  - Always stop machine if someone enters the area.
- R. Choke

#### Part Number 776310




This model is certified and is in compliance with European Directive 2006/42/EC.

#### Part Number 602562



Any maintenance operation that requires the removal of safety covers must be performed by a trained service technician.


#### Part Number 605251



The information shown on this decal is to be used in conjunction with the following models:

Hustler<sup>®</sup> Raptor<sup>®</sup> Flip-Up 935288CE Hustler<sup>®</sup> Raptor<sup>®</sup> Flip-Up 935452CE Hustler<sup>®</sup> Raptor<sup>®</sup> Flip-Up 938415CE Hustler<sup>®</sup> Raptor<sup>®</sup> Flip-Up 938860CE

	Part Number 601981
	 WARNING: Read Operator's Manual and decals before attempting to operate this machine.
	WARNING: Roll over!
	 <ul> <li>Operate a safe distance (minimum of 10 feet) away from drop-offs, retaining walls, drainage ditches, embankments, water, and other types of hazards to avoid a wheel dropping over the edge or to avoid the ground from breaking away.</li> </ul>
	 WARNING: Back over!
🔆 🙀	 • Do not carry passengers.
	<ul> <li>Always stop machine if someone enters the area.</li> </ul>
	 <ul> <li>Always be aware of what is behind the machine before backing up.</li> <li>Do not mow in reverse unless absolutely necessary. Always look down and behind before and while backing up.</li> </ul>
	 WARNING: Roll over!
	 Slow down before turning.
<15° ×	 <ul> <li>Do not operate on slopes greater than 15 degrees.</li> <li>Keep all movement on slopes slow and gradual. Never make sudden changes in speed and direction.</li> </ul>
	 • Do not operate on slopes above a retaining wall or drop-off.
	WARNING: Ejection!
	 <ul> <li>Do not operate on slopes greater than 15 degrees.</li> <li>Keep all movement slow and gradual when going up or down slopes.</li> </ul>
Ż.	 • Do not remove or modify stabilizer wheels or injury can result.
	WARNING: Loss of traction/control on slopes!
1. <b>•</b>	 • Shut off blades.
	 • Back slowly down the slope when loss of traction occurs.



- **3.** Fold the paper along the slope guide lines (C, D or E).
- **4.** Align the closest slope guide line with the ground slope. This will give you a close estimation of the ground slope to be mowed.

EN

EN

## **Safe Operating Practices**

Refer to the Safety Precautions section of this manual for operational and personal safety information.

## **Control Panel**




Figure 3-1

A. Deck clutch switch (Figure 3-1) – this switch engages the deck. Pull the switch up to engage and push the switch down to disengage the clutch.

For additional clutch information refer to the *Mower Deck Operation* section of this manual.

- B. Ignition switch (Figure 3-1) a three position switch: "OFF", "RUN", and "START". With the key inserted, rotate it clockwise to the "START" position; release the key when the engine starts, and the switch will automatically return to the "RUN" position.
- **C.** Throttle control (Figure 3-1) a cable is linked to the engine throttle for controlling engine speed. Move the lever forward to increase engine rpm, move the lever rearward to decrease engine rpm.
- **D.** Electronic hour meter (Figure 3-1) registers 1/10 hour increments up to 9,999.9 total hours. It is connected to the ignition switch. It records the accumulative time while the ignition key is switched to the "RUN" position.
- E. Deck lift switch (Figure 3-1) This switch activates the deck lift cylinder to raise and lower the deck.
- F. Fuel tank gauge (Figure 3-1) This gauge shows the fuel level in the fuel tank.
- G. Choke control (Figure 3-1) a cable is linked to manually operate the engine choke. When the knob is in the down position, the choke is in the "OFF" (run) position. When the knob is pulled up, the choke is in the "ON" (start) position. Do not operate the machine in the "ON" (start) position.

## Controls

A. Steering control levers (Figure 3-2 & Figure 3-3) – these levers control the mower's speed, direction, stopping, and park brake.


The parking brake may not hold the mower if parked on a slope. Block or chock the machine when parked on a slope.

**B.** Frame release lever (Figure 3-4) — this lever unlatches the deck to allow the deck to pivot when activating the flip-up feature.

Shown with steering control levers in the neutral position


A. Steering control lever

Figure 3-2



A. Steering control lever

Figure 3-3



ΕN

A. Frame release lever

Figure 3-4

## Safety Start Interlock System

The mower's safety start interlock system consists of the park brake switches, seat switch, and deck clutch switch.

**IMPORTANT:** Repair this important safety feature immediately if it malfunctions.

This safety feature prevents mower runaway or accidental entanglement during operation.

Check the mower's safety start interlock system daily, prior to operation.

To inspect the system:

- 1. Sit on the seat when testing the seat switch.
- 2. Set both steering control levers in the park brake position.
- **3.** Start the engine and allow it to warm up to operating temperature.
- **4.** With the deck clutch switch down and the steering control levers in the park brake position, slowly rise off of the seat. **The engine should continue to run.**
- 5. With the deck clutch switch up and/or the steering control levers in the neutral position, slowly rise off of the seat. The engine should stop.
- 6. If the engine fails to stop when:

- the deck clutch switch is up, or
- one or both of the steering control levers is up (neutral position), and
- the operator is off the seat, then
- check the function of the seat switch. Replace the seat switch if it is not operating properly (is not opening or closing) and if the cause can not be determined.

If you cannot locate the problem contact your Hustler® Dealer.

The safety interlock system should always function per steps 4 and 5. If it does not function properly, correct it immediately. Do not operate machine without a properly functioning seat safety switch.

## **Engine Starting**

The mower's safety start interlock system is also designed to protect the operator and others from accidental injury due to unintentional engine starting. The engine starting motor will not engage until:

- 1. Steering control levers are in the park brake position.
- 2. Deck clutch switch is in the down (OFF) position.
- **3.** Deck is in the operating position. The frame release lever is in the latched position and the frame release lever latch pin is in the inserted and locked position. Figure 3-5
- **4.** The deck lock pin must be in the operating position. Figure 3-6

The safety interlock system must not be disconnected or bypassed. Doing so could cause the machine to operate unexpectedly resulting in personal injury.

**NOTE:** The operator's seat is equipped with a separate safety switch. If for any reason the operator should become unseated when the steering control levers are not in the part brake position (park brake switches are disengaged) or the deck clutch switch is engaged the engine will stop.

Start the engine by following these steps. If you encounter difficulty, contact your Hustler® Dealer.

- 1. Before starting mower each day, perform daily preoperation checking. (*See Safety Start Interlock System section*.)
- 2. Make sure the steering control levers are in the park brake position and the deck clutch switch is disen-

WARNING





Figure 3-5



A. Deck lock pin

#### Figure 3-6

gaged. Start the engine from the operator's position only.

- **3.** Use the choke, if the unit is equipped with one, when the engine is cold, or if a warm engine fails to start within 5 seconds of cranking. Avoid flooding by operating the engine without choking as soon as possible.
- **4.** Set the throttle at approximately the 1/2 open position.

5. Insert the key in the ignition switch and rotate it clockwise to engage the starting motor. Release the key when the engine starts.

**IMPORTANT:** The engine starter should not be operated for periods longer than 30 seconds at a time. At least two minutes between such cranking periods to protect the starter from overheating and burning-out.

- **6.** Perform the test shown in the *Safety Start Interlock System* section to make sure the safety start interlock system operates properly.
- **7.** Allow the engine to idle two minutes before advancing the throttle and/or engaging the deck clutch.

## **Stopping the Engine**

Use the following procedure to shut the engine off.

- **1.** Place the steering control levers in the park brake position.
- 2. Throttle the engine back to low idle, then disengage the deck clutch. Refer to the *Mower Deck Operation* section for more details.
- **3.** Let the engine run at low idle for two minutes.
- **4.** Rotate the ignition key counter-clockwise to the "OFF" position. Remove the key from the switch before leaving the mower.

## Moving the Mower with Stalled Engine

The bypass valves on the transaxles allow the mower to be moved if the engine quits working.

Allow the engine exhaust manifold to cool before engaging or disengaging the bypass valves. The bypass valve rods are located close to the exhaust system.

Before moving the unit, pull out on the bypass valve rod (Figure 3-7) until the notch in the rod hooks over the edge of the slot. This places the bypass valves in the disengaged position.

Place the steering control levers in the neutral position, to release the park brakes, so that the mower can be moved.

Do not tow the machine. Move it by hand or use a winch to load onto a trailer for transporting.

Secure the mower, facing forward, when transporting on another vehicle. Tie the mower down securely using straps, chains, cables, or ropes. Both front and rear straps should be directed down and outward from the machine.

**IMPORTANT:** Always make certain the two bypass valves are returned to their operating position before running the mower following repairs.




Figure 3-7

To allow for easier deck servicing the deck can be flipped up to allow access to the underneath side of the deck. Goodbye jacks and dirty backs!™

**IMPORTANT:** This position is meant for servicing only. Never transport the mower with the deck in the service position. Never allow the drive tires to rise off of the ground.

#### IMPORTANT: The following sequences must be followed as shown or the frame will not pivot correctly.

1 – Adjusting pin in the transport position 2 – Ignition switch key in the "ON" position	Deck lock pin in the operating position	Deck lock pin in the service (flip-up) position
<ul> <li>A. Deck height adjusting pin</li> <li>B. Deck lift switch</li> <li>C. Ignition switch</li> </ul>	A. Deck lock pin	A. Deck lock pin
Figure 3-8	Figure 3-9	Figure 3-10
Frame release lever latch pin shown in the rotated or unlocked position	Frame release lever shown in unlatched position.	Frame release lever latch pin shown in in inserted and locked position. Frame
		release lever shown in latched position.

To rotate the deck to the service position use the following procedure:

- **1.** Park the mower on a level ground.
  - Raise the deck to the transport position and secure in place with the deck height adjusting pin. Figure 3-8
  - Disengage the deck clutch.
  - Shut the engine off.

ΕN

WARNING

- Place the steering control levers in the park brake position.
- Wait for all movement to stop before leaving the seat.

**IMPORTANT:** This feature will not work if the operator is on the seat.

**IMPORTANT:** Make sure the foot rest is clear of any items that may cause an obstructions when pivoting the mower frame to the service position.

When pivoting the mower frame to the service position make sure to stand clear of all moving parts. Keep clear of deck as it moves.

Keep all bystanders away from mower.

- 2. Chock the drive wheels in front and behind the tires.
- **3.** Rotate the ignition switch key to the "ON" position. Figure 3-8
- **4.** Push the deck lift switch down on the front side to extend the lift cylinder to full extension. Figure 3-8
- Move the deck lock pin from the upper hole (operating/ storage position) to the lower hole (service position).
   Figure 3-9 & Figure 3-10

**IMPORTANT:** Before unlatching the frame, make sure the deck lock pin is in the lower hole (service) position. If it is not, the frame will not pivot correctly which will result in the frame binding.

- 6. Pull out on the frame release lever latch pin. Rotate it a quarter of a turn to prevent it from re-engaging. Figure 3-11
- Pull the frame release lever to the rear until it will not move back and down to unlatch the frame lock. Figure 3-12

- 8. Push the deck lift switch (Figure 3-8) down on the back side and hold until the deck is in the fully raised position. Figure 3-14
- **9.** The deck is now in the service (flipped up) position. Figure 3-14

If the rear tires rise off the ground, **STOP**, release the switch and follow the instructions to return vehicle to the operating position.

WARNING

- **10.** Return the frame release lever to the latched position and push in on the frame release lever latch pin. Rotate it a quarter of a turn until it engages and locks the frame release lever in place. Figure 3-13
- **11.** Turn the ignition switch key to the "OFF" position.

**NOTE:** The battery will discharge if the switch is left in the "ON" position.

To rotate the deck to the mowing/operating position use the following procedure:

- Pull out on the frame release lever latch pin. Rotate it a quarter of a turn to prevent it from re-engaging. Figure 3-11
- Pull the frame release lever to the rear until it will not move back and down to unlatch the frame lock. Figure 3-12
- **3.** Rotate the ignition switch key to the "ON" position. Figure 3-8
- 4. Push the deck lift switch down on the front side and hold until the deck is in the operating position. Continue to hold the switch until the lift cylinder has reached full extension.
- 5. Turn the ignition switch key to the "OFF" position. Figure 3-8
- **6.** Pull the frame release lever to the front to latch the frame lock. Figure 3-13
- **7.** Push in on the frame release lever latch pin. Rotate it a quarter of a turn until it engages and locks the frame release lever in place. Figure 3-13
- 8. Remove the chocks from the drive wheels.
- **9.** Move the deck lock pin from the lower hole (service position) to the upper hole (operating/storage position). Figure 3-9 & Figure 3-10

**10.** Set the deck cutting height. Refer to the *Deck Cutting Height Adjustment* section for details.




Figure 3-14




Figure 3-15

## **Mower Operation**

This mower features the SmoothTrak<sup>™</sup> steering system. The following provides you with detailed information on how to operate the mower efficiently.

## **Driving the Mower**

Never make sudden stops or reverse direction, especially when maneuvering on a slope. The steering is designed for sensitive response. Rapid movement of the control levers in either direction could result in a reaction of the mower that can cause serious injury.

After starting the engine, engage the steering control levers and steer as follows:

**To go forward**, push the steering control levers forward an equal distance. Figure 3-16

**To go in reverse,** pull the steering control levers rearward an equal distance. Figure 3-16

**To turn left,** move the right steering control lever farther forward from neutral than the left steering control lever.

**To turn right,** move the left steering control lever farther forward from neutral than the right steering control lever. Figure 3-16

**Zero radius turn,** move one steering control lever forward and the other steering control lever back of neutral. This allows the drive wheels to counter-rotate. Figure 3-16

To stop or decrease speed, move steering control levers to neutral. When going forward pull back gently on steering control levers. When going in reverse push forward gently on steering control levers.

For emergency stops, when traveling forward or rearward, place the steering control levers in the park brake position immediately.

When moving in the rearward direction push forward gently on steering control levers and avoid sudden movement. Any sudden movement could cause the front of the mower to come off of the ground resulting in possible loss of control, causing serious injury or death.

## To make a three point turn to the right:

- **1.** Move the left steering control lever farther forward from neutral than the right steering control lever and start the turn. Figure 3-17
- **2.** Next, pull back on the steering control levers until they pass neutral and the machine starts to go rearward. Figure 3-17
- **3.** Pull the right steering control lever farther rearward from neutral than the left steering control lever until the rear of the machine pivots around. Figure 3-17
- 4. Then, push the steering control levers forward until they both pass neutral and the machine starts to go forward. Figure 3-17

ΕN

**5.** Push the left steering control lever farther forward from neutral than the right steering control lever and finish the turn. Figure 3-17

Always be aware of what is behind the machine before backing up. Do not mow in reverse unless absolutely necessary. Always look down and behind before and while backing up.

**IMPORTANT:** Damage to the hydraulic system components may occur with rapid movement of the steering controls.

To increase speed, increase the steering control lever's distance from neutral. The farther forward the steering control levers are from neutral, the faster the mower will travel forward. The farther back the steering control levers are from neutral, the faster the mower will go in reverse.




Figure 3-16




Figure 3-17

## **Operating Suggestions**

An inexperienced operator should not mow on slopes or on uneven terrain.
Before attempting normal speed operation an inexperienced operator should:

be thoroughly familiar with the proper use and operation of the equipment.

- read the manual completely and thoroughly.
- have attempted slow moving maneuvers.

If you lose steering control while operating the machine, place the steering control levers in the park brake position immediately. Inspect the machine and involve your Hustler<sup>®</sup> Dealer to resolve the problem before continuing to operate.

The unit's steering control levers are very responsive: Easy does it! For smooth operation, move the levers slowly, avoiding sudden movement. Skill and ease of operation come with practice and experience. The machine can spin very rapidly. Use caution when making turns and slow down before making sharp turns.

Inexperienced operators may have a tendency to oversteer and lose control. Practice slow maneuvers at low engine rpm (idle) on a flat open area before attempting normal speed operation.



Sharp depressions or raised obstacles (such as gutters or curbs) should not be directly approached at high speed in an attempt to "jump" them as the operator could be thrown from the equipment. Approach at a slow speed and angle one drive wheel at the obstruction. Continue at an angle until the wheel clears and then pivot the opposite wheel around.

When turning on soft wet turf, keep both wheels rolling either forward or backward. Pivoting on one stopped wheel can damage turf, especially when mowing.

Set the throttle at full rpm for maximum performance. This gives maximum power to the drive wheels and deck when needed. The throttle setting directly controls blade speed. Use the control levers to control ground speed rather than engine rpm.

Keep blades sharp. Many problems with incorrect cutting patterns are due to dull blades or blades which have been sharpened incorrectly. Information on sharpening blades is listed in this manual's maintenance section. Blade sharpness should be checked daily. ΕN

DANGER

Never work with blades while the engine is running or deck clutch switch is engaged (on).

Always place the deck clutch switch in the disengaged position, place steering control levers in the park brake position, turn the engine off and disconnect the negative battery cable.

Block the mower up when you must work under it.

Wear gloves when handling blades.

Always check for blade damage if the mower strikes a rock, branch or other foreign object during mowing!

Side Discharge Deck – Direct grass discharge to the right, away from the unmowed area. Generally, this means using a pattern of left turns. Avoid throwing grass discharge onto unmowed area. Mowing clippings puts an unnecessary load on the unit and reduces mowing efficiency.

EN

When mowing a lawn for the first time cut grass slightly longer than normal to avoid scalping uneven terrain. When cutting grass taller than six inches, you may want to mow the lawn twice to achieve a better quality of cut.

During normal mowing cut only about 1/3 of the grass blade.

Alternate the mowing direction to keep the grass growing straight and for better dispersion of the clippings.

**Remember, grass grows at different rates** at different times of the year. Mow more often in the early spring to maintain the same cutting height. As the growth rate slows in midsummer, mow less frequently. If you cannot mow at a regular interval, mow at a high cutting height; then mow again two days later at a lower cutting height.

**Raise the cutting height of the mower** if the cutting width of the mower is wider than the previous mower. This ensures that uneven turf is not cut too short.

**Raise the cutting height of the mower** if the grass is slightly taller than normal or if it contains a high degree of moisture. Then mow it again with the cutting height set lower.

If the machine's forward motion must be stopped while mowing, a clump of grass clippings may drop onto your lawn. To avoid this, move onto a previously cut area with the blades engaged.



Side Discharge Decks – Never direct the discharge of material from the mower deck toward bystanders.

• Never operate the mower deck with the discharge chute damaged, altered, removed, or in the raised position, except when the entire grass catcher attachment or mulching system is being used. Figure 3-18




Figure 3-18

A DANGER


Never attempt to make any adjustments to the mower deck while the engine is running or with the deck drive clutch engaged. Mower blades cannot be seen and are located very close to the deck housing. Fingers and toes can be cut off instantly.

## Flex Forks<sup>®</sup>

New Flex Forks<sup>®</sup> require a brief break-in period. Refer to the *Maintenance and Adjustments* section of this manual for more details.

## **Deck Clutch Operation**

Before beginning operation, check to make sure the deck clutch switch is engaging and disengaging the blades properly.



To check the deck clutch switch:

- 1. Start the engine and engage the deck clutch.
- 2. With the deck clutch switch up (clutch engaged) and the engine running, listen to confirm that the mower blades are rotating.
- **3.** Now, push the deck clutch switch down (clutch disengaged), and with the engine running, listen to confirm that the blades have stopped rotating.

4. If the mower blades continue to rotate with the deck clutch switch down, discontinue operation immediately and contact your Hustler® Dealer.

#### Follow these procedures to maximize clutch life.

1. Engage the clutch only when the throttle is set at approximately 2/3 throttle and there is no load on the blades. After clutch engagement, advance the engine throttle to full rpm.

Engaging the deck clutch at high engine rpm or when under heavy load (in tall grass, for example) can cause belts and/or electric clutch to slip, resulting in premature wear or possible damage.

2. Disengage the clutch only when the throttle is set at less than 1/2 throttle.

Never disengage the clutch with the engine running at high rpm. Setting the throttle to less than 1/2 throttle when disengaging the clutch will help extend clutch life.

**Warranty will not be allowed** for deck clutches that fail due to improper engagement and disengagement practices.


## **Deck Cutting Height Adjustment**

The deck cutting height is adjustable in 12.08 mm increments.

To adjust the cutting height:


- 1. Push the deck lift switch forward to release the pressure from the adjusting pin. Figure 3-19 & Figure 3-20
- 2. Pull the adjusting pin out of the hole that it is in and insert it into the desired cutting height hole. Figure 3-20
- **3.** Push the deck lift switch rearward until pressure is placed on the adjusting pin. Figure 3-19 & Figure 3-20

When transporting the mower push the deck lift switch forward to extend the deck lift cylinder to full extension. The cylinder will maintain that position for transporting or when going over obstacles.



A. Deck lift switch

Figure 3-19



A. Adjusting pin

Figure 3-20


## **Anti-Scalp Wheels**

Anti-scalp wheels are standard on these mowers. These wheels are designed to minimize scalping when mowing on rough uneven terrain. Figure 3-21

Anti-scalp wheels can be installed in two positions. With the wheel installed in the bottom hole, the wheel is located 40.6 mm below the mower blades. This setting is preferred when mowing at cutting heights of 63.5 mm or higher.

When the wheel is mounted in the top hole, it is located 17.8 mm below the mower blades. This is the acceptable setting for mowing at cutting heights of 38.1 mm or higher.

ΕN



REV D

## **MAINTENANCE & ADJUSTMENTS**

**WARNING** 

#### Safe Servicing Practices

Refer to the *Safety Precautions* section of this manual for more service safety information.

#### Service Introduction

Regular maintenance is the best prevention for costly downtime or expensive, premature repair. The following pages contain suggested maintenance information and schedules which the operator should follow on a routine basis. For more detailed information order the correct Parts Manual and General Service Manual for your unit. Refer to the *Product Literature* section of this manual for more information.

Remain alert for unusual noises, which could signal a problem. Visually inspect the machine for any abnormal wear or damage. A good time to detect potential problems is while performing scheduled maintenance service. Correcting the problem as quickly as possible is the best insurance.

Clear away heavy build-up of grease, oil and dirt, especially in the engine and hydraulic component areas; minute dust particles are abrasive to close-tolerance engine and hydraulic assemblies.

**Inspect mower daily** for grass clippings and wire or string tangles. The underside of the mower deck will collect a build-up of grass clippings and dirt, especially when grass is wet or has high moisture content. This build-up will harden, restricting blade and air movement which will probably result in a poorer quality of cutting. Therefore it should be removed routinely. To do this it will be necessary to raise and block the deck using jack stands or blocks in the full up position. Scrape the build-up off from underneath.

**IMPORTANT:** Seat arm rests – Place the steering control levers in the park brake position and pivot the arm rests upward before lifting the seat platform to prevent arm rest damage.

Some repairs require the assistance of a trained service mechanic and should not be attempted by unskilled personnel. Consult your Hustler<sup>®</sup> service center when assistance is needed.

## Torque Values

Particular attention must be given to tightening the drive wheel lug nuts and blade spindle bolts. Failure to correctly torque these items may result in the loss of a wheel or blade, which can cause serious damage or personal injury.

#### Torque values are given below:

	N∙m
Wheel (lug) nuts	.95
Blade spindle bolt top	.95
Blade spindle bolt bottom	160

**Lug nuts only -** It is recommended that these be checked after the first 2 hours of operation, initially, every 40 hours and following removal for repair or replacement.

For all other torques refer to the mower's *General Service Manual* for standard torque chart. See the *Product Literature* section for ordering information.

For engine torque values, refer to the engine owner's manual.

#### Tires

It is important for level mowing that the tires have the same amount of air pressure. The recommended pressures are:

**Only pneumatic tires are approved for the drive tires on this mower.** Warranty claims will be denied on any mower equipped with non-pneumatic tires.

#### Flex Fork<sup>®</sup> Break-In

Flex Forks<sup>®</sup> may raise the front of the mower approximately 1" when first installed. It is not necessary to re-level the deck at this time. Drive the mower for approximately 20 minutes, stop the mower and check to see if the deck is level. If adjustment is required, refer to the mower's General Service Manual for deck leveling procedures. EN

A DANGER A

Never attempt to make any adjustments to the mower deck while the engine is running or with the deck drive clutch engaged. Mower blades cannot be seen and are located very close to the deck housing. Fingers and toes can be cut off instantly.

#### Lubrication

Use SAE multi-purpose grease.

#### **Electrical System**

IMPORTANT: Refer to the *Safety* section of this manual for detailed battery servicing safety information.

The electrical system is a 12 volt, negative ground. The recommended battery size is:


Garden tractor BCI group U1R with a 225 or better cranking AMP rating.

A maintenance-free battery is recommended. Otherwise, follow battery manufacturer's maintenance, safety, storing and charging specifications.

#### System Fuses

The electrical system for this mower includes three fuses:

- A. Master in-line fuse (30 amp) Main fuse to protect the complete electrical system. It is located under the seat platform next to the solenoid. Figure 4-1
- B. Deck clutch fuse (15 amp) This fuse protects the deck clutch. It is located under the seat platform next to the battery. Figure 4-2
- C. Ignition/Safety system fuse (10 amp) This fuse protects the ignition and safety circuit components. It is located under the seat platform next to the battery. Figure 4-2



A. Master fuse housing

Figure 4-1




Figure 4-2

#### Hydraulic System

**NOTE:** Refer to the Raptor<sup>®</sup> Flip-Up General Service Manual (P/N 121535) for complete hydraulic oil and filter change procedures.

This mower is equipped with two integrated hydrostatic transmissions. Figure 4-3

**IMPORTANT:** Never use hydraulic or automatic transmission fluid in this system; use only the specified motor oil. Remember, dirt is the primary enemy of any hydraulic system.

The hydraulic expansion tank is located to the left of the engine. Figure 4-3

Check the oil level in the hydraulic system after every 40 hours of operation or weekly, whichever occurs first. Check more often if the system appears to be leaking or otherwise malfunctioning.

Use SAE 20W50 motor oil, 15W50 synthetic oil, or 20W50 synthetic oil when changing the system oil and filter. Hustler<sup>®</sup> Full Synthetic 20W50 Hydrostatic Transmission Oil is recommended.

When the hydraulic system oil is cold, the fluid level should be at the "Full Cold" line on the expansion tank.

Initial system oil and filter change **must** be after the first 75 hours of use or one (1) year whichever comes first. Thereafter, replace filter and oil in each transmission **every two (2) years or 200 hours, whichever comes first. NOTE:** The filter guard must be removed to access the filter. Figure 4-4

Each transmission's filter is located per Figure 4-4. A standard oil filter wrench is used to change filter, threads are right handed. **Use a Hustler® approved filter element only**.

**IMPORTANT:** When washing the mower, direct the spray away (especially if using a power washer) from the transmission's seals to prevent water intrusion and to ensure component performance.



A. Expansion tank

Figure 4-3

## **Fuel and Evaporative Emissions Control System**


IMPORTANT: Refer to the *Safety* section of this manual for fuel handling safety information.

IMPORTANT: Refer to the engine owner's manual for additional emissions control information.

The fuel and evaporative emissions control system for this mower is EPA compliant. Use only Hustler<sup>®</sup> approved replacement parts.

Your evaporative emission control system may include parts such as:

- fuel tanks
- fuel lines
- fuel line fittings
- fuel caps



- carbon canisters
- canister mounting brackets
- carburetor purge port connection
- filters
- vapor hoses
- clamps, control valves
- control solenoids
- electronic controls
- vacuum control diaphragms
- purge valves
- liquid/vapor separator
- · other associated components

Modifying or Tampering with the evaporative emissions control system or the fuel system is prohibited. Federal law and California State law prohibit the following acts or the causing thereof:

- The removal or rendering inoperative by any person other than for purposes of maintenance, repair, replacement, of any device or element of design incorporated into any equipment for the purposes of emissions control prior to or after its sales or delivery to the ultimate purchaser or while it is in use, or
- **2.** The use of the equipment after such device or element of design has been removed or rendered inoperative by any person.


Use of replacement parts not equivalent to the original parts may result in system failure and pose a safety hazard.

The fuel tank is located under the seat platform with the filler neck and fuel cap located in the left side fender. Figure 4-5

Park the mower on level ground before filling fuel tank.


Clean the area around the fuel cap before removing the cap. Remove the fuel cap slowly.

When threading the fuel cap onto the filler neck, tighten the cap until it begins to click, then, continue to turn it until at least three clicks are heard.






**IMPORTANT:** Do not overfill the fuel tank. The fuel tank should be filled **no higher than the bottom of the fill neck.** The fuel system is designed to leave room for the fuel to expand with fuel temperature changes. Figure 4-6



Use regular unleaded gasoline with an octane rating of 87 or higher. Maximum of 10% ethanol (E10) in fuel. Fuels with greater than 10% ethanol (such as E15, E20 and E85) voids warranty. Fuels with greater than 10% ethanol are not




approved for use and such illegal use could cause equipment failure and pose a fire hazard.

Refer to the *Engine Owner's Manual* for additional fuel specification requirements.

#### **Fuel Shut-off Valve**

This mower is equipped with a fuel shut-off valve, located in between the fuel tank and the mower frame crossmember. When closed the fuel valve prevents fuel flow to the engine. Figure 4-7





## **Engine Oil and Filter**

If the engine has been running and is up to operating temperature, allow the engine to cool before changing the oil. Engine and engine oil will be very hot, so be very careful when changing oil and wear the appropriate protective gear to avoid being burned or exposed to engine oil.

Check engine oil daily and after every 4 hours of operation. Mower must be on a level surface when checking oil. Refer to engine manual and maintenance schedule for oil recommendation and capacities. Hustler<sup>®</sup> Motor Oil is recommended.

ΕN

WARN NG

Change the engine oil and filter after the first 5 hours of operation and then per the engine manufacturer's recommendations after that. If mower is being operated in extremely dirty conditions, then it is recommended oil be changed more frequently.

**IMPORTANT:** After the new oil filter has been installed, clean up any oil which may have spilled onto the engine plate, engine exhaust system, and muffler guard.

#### Draining the Engine Oil:

- 1. Locate the oil drain valve on the lower right side of the engine. Figure 4-8
- 2. Locate the oil drain hose that was supplied with the machine. Be sure to clean and clear it of debris that might block the flow of the engine oil. Figure 4-8
- **3.** Attach one end of the hose onto the oil drain valve nipple. Make sure the hose is pushed all the way onto the valve. Figure 4-8
- **4.** Position the loose end of the hose forward and down in front of the right side transmission so that it can drain into a suitable oil drain container.
- 5. With the hose in position, use a 10 mm wrench or socket and open the valve approximately 4 turns in the counterclockwise direction. Allow 10 minutes for engine oil to adequately drain.
- **6.** After oil is drained, close the valve by turning it in the clockwise direction until it is fully closed.
- 7. Once the valve is closed, carefully remove the oil drain hose and clean up any spilled oil.

**IMPORTANT:** All oil drips or spills **must** be cleaned off of the engine plate, engine exhaust system, and muffler guard before operating the machine.

8. Clean the oil drain hose and store it appropriately. Figure 4-8




Figure 4-8

## **Engine Air Filter**


Perform engine air filter maintenance per the *Maintenance Schedule* shown elsewhere in this manual.

## **General Engine Maintenance**

Detailed instructions and recommendations for break-in and regular maintenance are specified in the *Engine Owner's Manual*. Please refer to this manual for engine servicing, lubricating oil levels with quality and viscosity recommendations, bolt torques, etc. The engine warranty is backed by the engine manufacturer. Special attention should be paid to applicable data which will not be duplicated here.

## **Fuel Evaporation System Filter**

These mowers have a fuel evaporation system filter. This filter must be checked and replaced every 100 hours or annually whichever comes first. Figure 4-9



**A.** Fuel evaporation system filter

Figure 4-9

#### Belts

Inspect belts frequently for wear and serviceability. Replace a belt that shows signs of:

- severe cuts
- tears
- separation
- weather checking
- cracking
- burns caused by slipping.

Slight raveling of belt covering does not indicate failure, trim ravelings with a sharp knife.

MARNING

If the pump belt fails, loss of control will occur especially when operating on a slope. If you lose steering control while operating the machine, place the steering control levers in the park brake position immediately. Inspect the machine and involve your Hustler<sup>®</sup> Dealer to resolve the problem before continuing to operate.

Inspect the belt pulley grooves and flanges for wear. A new belt, or one in good condition, should never run against the bottom of the groove. Replace the pulley when this is the case, otherwise the belt will lose power and slip excessively.

Never pry a belt to get it on a pulley as this will cut or damage the fibers of the belt covering.

Keep oil and grease away from belts, and never use belt dressings. Any of these will destroy the belt composition in a very short time.

#### Mower Blades

#### **Mower Blade Maintenance**

IMPORTANT: Refer to the *Safety* section of this manual for blade handling safety information.

Refer to the *Mower Blade Replacement* section for blade removal and installation.

Mower blades are sharp and can cut. Wrap the blade(s) or wear gloves and use extra caution when servicing them.

Check the mower blades daily, they are the key to power efficiency and well groomed turf. Keep the blades sharp. A dull blade will tear rather than cut the grass, leaving a brown ragged top on the grass within a few hours. A dull blade also requires more power from the engine.

Replace any blade which is bent, cracked or broken.

#### Always check for blade damage:

- if mower strikes a rock, branch or other foreign object during mowing!
- or if an abnormal vibration occurs while operating.


Make all necessary repairs before resuming operation.

Sharpen the blades following the pattern shown. Touch-up sharpening can be done with a file. Figure 4-10


After grinding the blades, check for balance. Blade balancing can be done by placing the blade on an inverted line punch or 5/8" bolt. A commercial balancing tool is also available through most hardware supply stores.

The blade should not lean or tilt. When spinning the blade slowly it should not wobble. Balance the blade before reinstalling.

Lay the blade on a flat surface and check for distortion. Replace any distorted blade. Figure 4-11 & Figure 4-12









EN

End view of blades, comparing twisted and straightened blades.





Figure 4-12


### Mower Blade Removal

IMPORTANT: Refer to the *Safety* section of this manual for blade handling safety information.



A 15/16" wrench is required to remove the 5/8" cap screw holding the blade to the spindle shaft. **NOTE**: A blade holding tool (P/N 381442) is available from Hustler® Turf Equipment. It is designed to prevent the blades from rotating when they are being removed or installed on the spindle. Contact your Hustler® Dealer for more information.

Do not re-use spindle bolts which have stripped, worn or undercut threads. Torque bolts on spindles to 160.0 N·m when reinstalling blades.



Properly compressed cup washers maintain the correct compression load on the blades. Replace the cup washers if they are cracked or flattened.

**IMPORTANT:** The blade sail (curved part) must be pointing upward toward the inside of the deck to ensure proper cutting.

When mounting blades, rotate them after installation to ensure blade tips do not touch each other or sides of the mower.

### **Mower Blade Options**

DANGER

The following is a list of the approved mower blade options that are available from Hustler<sup>®</sup> Turf Equipment for this mower.

Use only genuine Hustler<sup>®</sup> replacement blades to ensure that original standards are maintained. Failure to use approved blades could lead to blade breakage which could result in death, injury or property damage.

48" Side Discharge Deck				
796623	BLADE, 16.50"-MUL-F-CW			
601123	BLADE, 16.50"-L-F-CW			
796631	BLADE, 16.50"-GAT-F-CW			
795757	BLADE, F16.50"-H-F-CW			
54" Side Discharge Deck				
797704	BLADE, 18.50"-MUL-F-CW			
601124	BLADE, 18.50"-L-F-CW			
797712	BLADE, 18.50"-GAT-F-CW			
797696	BLADE, F18.50"-H-F-CW			
48" Rear Discharge Deck				
601123	BLADE, 16.50-L-F-CW			
796623	BLADE, 16.50"-MUL-F-CW			
796631	BLADE, 16.50"-GAT-F-CW			

### Seat Adjustment

The seat on the Hustler<sup>®</sup> Raptor<sup>®</sup> Flip-Up mower can be adjusted forward and rearward by pivoting the seat platform up and forward. Then, loosen the four cap screws on the underneath side of the seat platform. Position the seat where you have the best control of the machine and are the most comfortable and then tighten the cap screws. Figure 4-13




Figure 4-13

### **Steering Control Lever Adjustment**

The steering control levers can be adjusted for operator comfort.

- A. To pivot the upper control levers forward or rearward, loosen the cap screws that attach the upper control lever to the lower lever. Then, pivot the upper control lever. Tighten the cap screws. Figure 4-14
- **B.** To lower and raise the control levers, remove the cap screws. Slide the upper control lever up or down and align the holes in it with the holes in the lower lever. Re-install the cap screws and tighten.

The steering control levers should be adjusted so that they align with each other when in the neutral position.





Figure 4-14


### Maintenance Schedule Refer to Figure 4-15, Figure 4-16, Figure 4-17, Figure 4-18, Figure 4-19 & Figure 4-20

	-	
	WEEKLY OR 40 HOURS	* ANNUALLY OR 100 HOURS
Verify safety start interlock system	Prior to e	each use
Visually inspect unit for loose hardware and/or damaged parts	Prior to e	each use
Visually inspect tires	Prior to e	each use
Check oil level, engine (1)	Prior to each use	or every 4 hours
Clean air intake screen (8)	Prior to each use	or every 4 hours
Check fuel level	Prior to e	each use
Blades - sharpen & securely fastened	Prior to e	each use
Discharge chute - securely in place & in lowest position	Prior to e	each use
Clean engine and transaxle compartment (11)	After ea	ach use
Replace engine air cleaner element (4)(10)	As ne	eded
Change transaxle oil and filter (7)	Every 200 ho	urs or 2 years
Grease front wheel bearings	X	
Grease deck height pivots	X	
Change engine oil & filter (1)(3)	X	
Clean cylinder and head fins (10)	X	
Check battery connections (11)	X	
Clean engine exterior (10)	X	
Tighten lug nuts on wheels (2)	X	
Check tire pressure with a gauge	X	
Check hydraulic oil level	X	
Clean & regap spark plugs (10)		Х
Check transaxle & deck belt tension and condition (5) (11)		Х
Check hydraulic lines (11)		Х
Check fuel system (6)(11)		Х
Check fuel valve (6)		Х
Check fuel tank grommet (6)		Х
Change fuel filter (6)		Х
Replace fuel evaporation system filter (8)		Х
Replace spark plugs (10)		х
Grease frame pivot joints (9)		Х
Grease frame pivot lock joints (9)		Х

### NOTES:

- 1. Initial engine oil change is after 5 hours of operation. Thereafter, change oil after every 40 hours operation. Change more often under dusty or dirty conditions and during hot weather periods. Hustler<sup>®</sup> Motor Oil is recommended.
- 2. Torque initially and after first 2 hours of operation.
- 3. Change engine oil filter per the engine manufacturer's recommendations. Refer to Engine Owner's Manual for recommendations and other maintenance items.
- 4. Service more often under dusty or dirty conditions. Use caution when servicing to prevent dust contamination in the engine. Do not clean filter element. Replace with a new one.
- 5. Pump drive belt only Inspect every month and replace if worn or cracking is noticed. Otherwise, replace every 2 years.
- 6. Check fuel system for any cracks or leaks including, but not limited to, fuel line hoses, fuel valve, vent line hoses, vent valve, vapor valve, carbon canister, and grommets. Replace as needed.
- 7. Initial transaxle system oil and filter change **must** be after the first 75 hours of use or 1 year whichever comes first. Thereafter, replace filter and oil in each transaxle **every 2 years or 200 hours,** whichever comes first. Hustler<sup>®</sup> Full Synthetic Hydrostatic Transmission Oil is recommended.
- 8. More often under dusty or dirty conditions and during hot weather.
- 9. Do not over grease. Wipe off any excess grease.
- **10.** Refer to engine owner's manual for engine service information.
- 11. Any maintenance operation that requires the removal of safety covers **must** be performed by a trained service technician.





### **Maintenance Record**

Perform the initial hydraulic system oil and filter change after the first 75 hours of use or yearly whichever comes first.

Date:       Maintenance/Service Performed:       Dealer:         Hour Meter Reading:       Hour Meter Reading:       Date:       Maintenance/Service Performed:         Date:       Maintenance/Service Performed:       Date:       Maintenance/Service Performed:			Date:	Maintenance/Service Performed:
Hour Meter Reading:       Maintenance/Service Performed:       Date:       Maintenance/Service Performed:         Dealer:       Date:       Maintenance/Service Performed:       Date:       Maintenance/Service Performed:         Hour Meter Reading:       Hour Meter Reading:       Maintenance/Service Performed:       Date:       Maintenance/Service Performed:         Date:       Maintenance/Service Performed:       Date:       Maintenance/Service Performed:       Date:         Date:       Maintenance/Service Performed:       Date:       Maintenance/Service Performed:       Date:         Hour Meter Reading:       Maintenance/Service Performed:       Date:       Maintenance/Service Performed:         Date:       Date:       Date:       Date:       Maintenance/Service Performed:         Date:       Date:       Date:       Date:       Date:       Maintenance/Service Performed:         Dealer:       Date:       Date:       Date:       Date:       Date:       Maintenance/Service Performed:         Hour Meter Reading:       Hour Meter Reading:       Date:       Maintenance/Service Performed:       Date:         Hour Meter Reading:       Hour Meter Reading:       Date:       Maintenance/Service Performed:       Date:		Maintenance/Service Performed:	Dealer.	
Hour Meter Reading:     Date:     D	Dealer:			
Hour Meter Reading:     Date:     D				
Hour Meter Reading:     Maintenance/Service Performed:     Date:     Maintenance/Service Performed:       Date:     Date:     Date:     Date:       Hour Meter Reading:     Hour Meter Reading:     Date:     Date:       Date:     Date:     Date:     Date:       Date:     Date:     Date:     Date:       Date:     Date:     Date:     Date:       Date:     Date:     Date:     Date:       Date:     Maintenance/Service Performed:     Date:     Date:       Date:     Maintenance/Service Performed:     Date:     Date:       Date:     Maintenance/Service Performed:     Date:     Date:       Date:     Date:     Date:     Date:       Date:     Maintenance/Service Performed:     Dealer:       Date:     Date:     Date:       Hour Meter Reading:     Date:     Date:       Date:     Date:     Date:				
Date:     Date:     Date:     Dealer.       Hour Meter Reading:     Hour Meter Reading:     Date:     Date:       Date:     Maintenance/Service Performed:     Date:       Date:     Date:     Maintenance/Service Performed:       Date:     Maintenance/Service Performed:     Date:       Hour Meter Reading:     Hour Meter Reading:     Maintenance/Service Performed:       Hour Meter Reading:     Hour Meter Reading:     Maintenance/Service Performed:       Hour Meter Reading:     Date:     Maintenance/Service Performed:       Hour Meter Reading:     Date:     Maintenance/Service Performed:			Hour Meter Reading:	
Date:       Maintenance/Service Performed:       Dealer:         Dealer:       Dealer:         Hour Meter Reading:       Hour Meter Reading:         Date:       Date:         Date:       Date:         Dealer:       Date:         Date:       Dealer.         Date:       Dealer.         Dealer:       Dealer.         Date:       Dealer.         Date:       Maintenance/Service Performed:         Date:       Date:	Hour Meter Reading:			
Dealer:     Image: Service Performed:     Image: Service Performed:     Image: Performed: Service Performed:     Image: Performed: Per	Date:	Maintenance/Service Performed:		Maintenance/Service Performed:
Hour Meter Reading:     Maintenance/Service Performed:     Date:     Maintenance/Service Performed:       Dealer:     Date:     Date:     Date:       Hour Meter Reading:     Hour Meter Reading:     Date:     Date:       Date:     Date:     Date:       Hour Meter Reading:     Maintenance/Service Performed:     Date:       Hour Meter Reading:     Maintenance/Service Performed:     Date:       Hour Meter Reading:     Maintenance/Service Performed:     Date:       Hour Meter Reading:     Date:     Maintenance/Service Performed:       Hour Meter Reading:     Hour Meter Reading:     Maintenance/Service Performed:	Dealer:		Dealer.	
Hour Meter Reading:     Maintenance/Service Performed:     Date:     Maintenance/Service Performed:       Dealer:     Date:     Date:     Date:       Hour Meter Reading:     Hour Meter Reading:     Date:     Date:       Date:     Date:     Date:       Hour Meter Reading:     Maintenance/Service Performed:     Date:       Hour Meter Reading:     Maintenance/Service Performed:     Date:       Hour Meter Reading:     Maintenance/Service Performed:     Date:       Hour Meter Reading:     Date:     Maintenance/Service Performed:       Hour Meter Reading:     Hour Meter Reading:     Maintenance/Service Performed:				
Hour Meter Reading:     Maintenance/Service Performed:     Date:     Maintenance/Service Performed:       Dealer:     Date:     Date:     Date:       Hour Meter Reading:     Hour Meter Reading:     Date:     Date:       Date:     Date:     Date:       Hour Meter Reading:     Maintenance/Service Performed:     Date:       Date:     Date:     Date:       Hour Meter Reading:     Maintenance/Service Performed:     Date:       Hour Meter Reading:     Maintenance/Service Performed:     Date:       Hour Meter Reading:     Maintenance/Service Performed:     Dealer:       Hour Meter Reading:     Hour Meter Reading:     Maintenance/Service Performed:				
Hour Meter Reading:       Maintenance/Service Performed:       Date:       Da				
Date:       Maintenance/Service Performed:       Dealer:         Dealer:       Pealer:       Pealer:         Hour Meter Reading:       Hour Meter Reading:       Date:         Date:       Maintenance/Service Performed:       Date:         Dealer:       Pealer:       Pealer:         Date:       Maintenance/Service Performed:       Date:         Dealer:       Pealer:       Pealer:         Dealer:       Pealer:       Pealer:         Dealer:       Pealer:       Pealer:         Pealer:       Pealer:       Pealer:         Dealer:       Pealer:       Pealer:         Pealer:       Pealer:       Pealer:         Peale:       Pealer:       Pealer:         Peale:       Pealer:       Pealer:         Peale:       Pealer:       Pealer:         P	Hour Meter Reading:		Hour Meter Reading:	
Dealer:     Dealer:     Dealer:       Hour Meter Reading:     Hour Meter Reading:       Date:     Date:       Dealer:     Date:       Dealer:     Date:       Hour Meter Reading:     Date:       Dealer:     Date:			Date:	Maintenance/Service Performed:
Hour Meter Reading:     Hour Meter Reading:       Date:     Date:       Dealer:     Date:       Hour Meter Reading:     Hour Meter Reading:       Hour Meter Reading:     Dealer:       Hour Meter Reading:     Hour Meter Reading:       Hour Meter Reading:     Hour Meter Reading:		Maintenance/Service Performed:	Dealer.	
Hour Meter Reading:     Maintenance/Service Performed:     Date:     Date:     Maintenance/Service Performed:       Dealer:     Dealer:     Dealer:     Dealer:     Hour Meter Reading:       Hour Meter Reading:     Date:     Date:     Maintenance/Service Performed:	Dealer.			
Hour Meter Reading:     Maintenance/Service Performed:     Date:     Date:     Maintenance/Service Performed:       Dealer:     Dealer:     Dealer:     Dealer:     Dealer:     Dealer:       Hour Meter Reading:     Hour Meter Reading:     Date:     Maintenance/Service Performed:				
Hour Meter Reading:     Maintenance/Service Performed:     Date:     Date:     Maintenance/Service Performed:       Dealer:     Dealer:     Dealer:     Dealer:     Dealer:     Dealer:       Hour Meter Reading:     Hour Meter Reading:     Date:     Maintenance/Service Performed:				
Date:     Date:     Date:     Maintenance/Service Performed:       Dealer:     Dealer:     Dealer:       Hour Meter Reading:     Hour Meter Reading:     Date:			Hour Meter Reading:	
Date:       Maintenance/Service Performed:       Dealer.         Dealer.       Dealer.         Hour Meter Reading:       Hour Meter Reading:         Date:       Date:	Hour Meter Reading:			
Dealer: Hour Meter Reading: Dealer: Hour Meter Reading: Date: Maintenance/Service Performed:	Date:	Maintenance/Service Performed:		Maintenance/Service Performed:
Hour Meter Reading:     Date:     Maintenance/Service Performed:	Dealer:		Dealer.	
Hour Meter Reading:     Date:     Maintenance/Service Performed:				
Hour Meter Reading:     Date:     Maintenance/Service Performed:				
Hour Meter Reading:     Date:     Maintenance/Service Performed:				
	Hour Meter Reading:		Hour Meter Reading:	
			Date:	Maintenance/Service Performed:
Dealer.	Date:	Maintenance/Service Performed:	Dealer.	
Dealer.	Dealer:			
Hour Meter Reading:			Hour Meter Reading:	
Hour Meter Reading:	Hour Meter Reading:			

# TROUBLESHOOTING

The majority of operating problems that occur with a system can be traced to improper adjustments or delayed service. A consistently applied preventative maintenance program, as outlined in the *Maintenance* section of this manual, will prevent many problems. The following chart is designed to help you locate a problem by suggesting probable causes and the recommended solutions.

SYMPTOMS	PROBABLE CAUSES	SUGGESTED REMEDIES
Starting motor does not crank	Steering control levers not in park brake position or switch not adjusted	Place steering control levers in park brake posi- tion or re-adjust switch
	Deck clutch switch engaged	Disengage clutch switch
	Frame release lever is not in the latched position	Place the frame release lever in the latched posi- tion and engage the frame lever release latch pin.
	Weak or dead battery	Recharge or replace
	Electrical connections are corroded or loose	Check the electrical con- nections
	15 amp fuse is blown	Replace the 15 amp fuse
	For additional causes	See engine manual
The engine will not start, starts hard or fails to keep running	No fuel or line plugged	Fill tank or replace line (See <i>Fuel System</i> section for more details)
	There is incorrect fuel in the fuel system	Drain the tank and replace the fuel with the proper type
	There is dirt in the fuel filter	Replace the fuel filter
	Dirt, water or stale fuel in the fuel system	Contact your Dealer
	The choke is not on (if equipped)	Move the choke lever to ON
	Numerous	See engine manual
Engine: Runs with continuous misfiring or engine runs unevenly or erratically	Numerous	See engine manual
Loss of power or system will not operate in either	Restrictions in air cleaner	Service air cleaner
direction	Poor compression	Contact your Dealer
	Steering linkage needs adjustment	Adjust linkage
	Tow valve open	Close tow valve
	The traction drive belt is worn, loose or broken	Install a new traction drive belt
	For additional causes	See engine manual
Air cooled engine over- heating	Air intake screen or cooling fins clogged	Clean screen and fins
	For additional causes	See engine manual
Low engine oil pressure	Low oil level	Add oil
	Oil diluted or too light	Change oil and check for source of contamination
	Failed oil pump	Contact your Dealer
High oil consumption	Numerous	Contact your Dealer

		SUGGESTED	
SYMPTOMS	PROBABLE CAUSES	REMEDIES	
Mower jerky when start- ing or operates in one direction only	Steering control linkage needs adjustment	Adjust linkage	
direction only	Loose steering linkage	Tighten linkage	
	Transaxle component faulty	Contact your Dealer	
Mower creeps when steering control levers are in neutral	Steering linkage needs adjustment	Adjust linkage	
Mower circles or veers in one direction	Steering linkage needs adjustment	Adjust linkage	
	Loose steering linkage	Tighten linkage	
	Tires improperly inflated	Adjust air pressure to 55– 83 KPa	
	Transaxle component faulty	Contact your Dealer	
Mower creeps when park- ing brake engaged	Steering linkage out of adjustment	Adjust steering linkage	
	Brakes need adjustment	Adjust parking brakes	
There is abnormal vibra- tion	The engine mounting bolts are loose	Tighten the engine mount- ing bolts	
	The engine pulley, idler pul- ley or blade pulley is loose	Tighten the appropriate pulley	
	The engine pulley is dam- aged	Contact your Dealer	
	The cutting blade(s) is/are bent or unbalanced	Install new cutting blade(s)	
	A blade mounting bolt is loose	Tighten the blade mount- ing bolt	
	Spindle bearing is worn or loose	Replace or tighten spindle bearing	
	A blade spindle is bent	Contact your Dealer	
Blades do not rotate	The deck drive belt is worn, loose or broken	Install a new deck drive belt	
	The deck drive belt is off the pulley	Install the deck drive belt and check for a reason	
	Electric clutch is not engaging	Check and/or replace 15 amp fuse. Contact your Dealer	

ΕN

SYMPTOMS	PROBABLE CAUSES	SUGGESTED REMEDIES
Uneven cutting height	The blade(s) are not sharp	Sharpen the blades
	A cutting blade(s) is/are bent	Install new cutting blade(s)
	The deck is not level	Level the deck per the <i>Deck</i> <i>leveling</i> section of the Gen- eral Service Manual
	An anti-scalp wheel is not set correctly	Adjust the height of the anti-scalp wheel
	The underside of the deck is dirty	Clean the underside of the deck
	Tires improperly inflated	Adjust air pressure to 55 <del>–</del> 83 KPa
	A blade spindle is bent	Contact your Dealer
	Flex Forks <sup>®</sup> are installed	After initial break-in period, level the deck per the Deck Leveling section of the General Service Manual.
Frame will not pivot to the service position.	Deck lock pin not in the ser- vice (flip-up) position.	Place deck lock pin in the service (flip-up) position.
	Numerous	Contact your Dealer

WARNING

4

WARNING

When storing the unit at the end of the mowing season, the mower, engine, and battery should have the following items serviced before storage.

If the mower has been stored for an extended period of time, follow the new season preparation steps before beginning operation.

### **General Mower Preparation for Storage**

**1.** Remove all grass, dirt, and trash from mower and cutting units.

**IMPORTANT:** Wash the machine with a mild detergent and water. Do not pressure wash the machine. Avoid excessive use of water, especially near the control panel and engine.

- **2.** Clean mower and deck and touch up all scrapes with touch-up paint.
- 3. Install new air filter per Engine Owner's Manual.
- **4.** Check thoroughly for any worn or damaged parts that need replacing and order them from your dealer.
- **5.** Thoroughly lubricate machine, according to the *Main-tenance* section.
- **6.** Block mower up so weight is off tires. Check tire pressure and inflate to proper operating pressure.

NOTE: Do not deflate tires.

**IMPORTANT:** Do not store the mower with the deck in the service (flipped-up) position.

- 7. Perform separate engine and battery preparation as listed below.
- 8. Store mower in a clean, dry place.

### **Preparation of Engine for Storage**

If the mower is to be unused for an extended period of time (30 days or more), the engine will need to be prepared for storage. Use the following procedures before storing the mower.

**IMPORTANT:** Refer to the *Fuel Handling Precautions* section of this manual for important safety information before proceeding.

- Add a Hustler<sup>®</sup> approved fuel stabilizer to the fuel system. Refer to the instructions shown on the fuel stabilizer bottle for proper usage. Hustler<sup>®</sup> Fuel Stabilizer with Cleaner is recommended. For detailed information consult with your Dealer.
- 2. Fill the fuel tank(s) with fresh fuel.

NOTE: Use non-ethanol fuel if possible.

# To prevent carbon monoxide poisoning, operate the engine in a well ventilated area only.

**3.** Run the engine for a minimum of 10 minutes.

Allow the engine to cool before changing the engine oil. Use caution when changing the engine oil as it will be very hot. You should wear the appropriate protective gear to avoid being burned or exposed to engine oil.

- **4.** Drain the oil from the crankcase while the engine is still warm.
- 5. Replace the engine oil filter.
- 6. Refill with fresh oil of the proper viscosity. Hustler® Motor Oil is recommended.
- 7. Close the fuel shut-off valve (if equipped).
- **8.** Check the oil filler cap and fuel tank cap(s) to make certain they are securely in place.
- 9. Refer to the engine manual for more information.

### **Preparation of Battery for Storage**

When the machine is to be unused for long periods, it is best to disconnect the battery and remove it from the unit. At this time perform the following battery maintenance:

- 1. Remove the battery from machine.
- 2. Clean the battery, terminals, and cable connectors.
- 3. Charge the battery, if necessary.
- **4.** Store the battery in a cool, dry place (do not expose to freezing temperatures).
- **5.** Always keep the battery fully charged. Especially important to prevent battery damage when the temperature is below 0°C.

### **New Season Preparation**

Before starting the mower following post season storage, the following service is required:

- 1. Clean mower, removing trash and dirt accumulation.
- 2. Check engine oil and hydraulic oil levels.
- **3.** Install fully charged battery and attach the battery cables.

4. Fill fuel tank(s) with fresh fuel. Run machine at half speed for 5 minutes, checking operation of steering control levers. Stop engine and check for oil leaks, loose fittings and so forth.

# V WARNING

At start of new season always check that fresh oil has been added to machine. If oil is drained at season's end and not replaced, engine damage will result.

- 5. Tighten any bolts that have loosened and make sure all hair pins, cotter pins and clevis pins are in place.
- **6.** Install all safety shields and review safety precautions listed in this manual.
- 7. Check and inflate tires to 55-83 KPa.
- **8.** Refer to engine manual for more information.

# **TECHNICAL SPECIFICATIONS**

# Hustler<sup>®</sup> Raptor<sup>®</sup> Flip-Up

	Guaranteed Sound Power Level	Operator Ear	* Engine RPM	** Vibration (Maximum weighted acceleration m/s2 - whole body)	Machine Mass	Nominal Engine Power	Cutting Width
Model No.	dBA	dBA	RPM	m/s2	kg	kW	cm
935288CE	105	91.0	3050 (± 50)	0.42	344	16.3	122
935452CE	105	90.3	3050 (± 50)	.639	369	15.4	122
938415CE	105	91.3	3050 (± 50)	1.36	348	16.3	122
938860CE	105	90.6	2900 (± 50)	1.69	362	15.8	122
Sound Measurements (dBA)	Sound Power per Hemisphere method (ISO 3744 - 1994 and 11094 - 1991 and ISO 3744:2010))						
* IMPORTANT:	Never alter or ta	amper with the e	engine speed (RI	PM) settings.			
** Whole Body	upon the rough	ness of the grou	und, the speed at	3 minutes on a representa t which the mower is oper according to STD Procedu	ating and the op	erator driving ha	•

Hand/Arm	These values were obtained through hand/arm measure per ISO 5349-1-2001.
Model No.	
935288CE	The RMS acceleration in m/s <sup>2</sup> measured in 24 seconds is less than 2.5 m/s <sup>2</sup> .
935452CE	The RMS acceleration in m/s <sup>2</sup> measured in 24 seconds is less than 2.5 m/s <sup>2</sup> .
938415CE	The RMS acceleration in m/s <sup>2</sup> measured in 24 seconds is greater than 2.5 m/s <sup>2</sup> .
938860CE	The RMS acceleration in m/s <sup>2</sup> measured in 24 seconds is greater than 2.5 m/s <sup>2</sup> .
st was performe	d on a static (stationary) machine.

EN

EN

## INDEX

Anti-Scalp Wheels
Battery Service Precautions
Belts
Children 2-4
Control Panel 3-1
Controls
Deck Clutch Operation
Deck Cutting Height Adjustment
Draining the Engine Oil 4-5
Driving the Mower
Electrical System 4-2
Engine Air Filter 4-5
Engine Oil and Filter 4-4
Engine Starting 3-2
Flex Fork® Break-In 4-1
Flex Forks <sup>®</sup>
Fuel and Evaporative Emissions Control System 4-3
Fuel Evaporation System Filter    4-5
Fuel Handling Precautions
Fuel Shut-off Valve 4-4
General Engine Maintenance
General Mower Preparation for Storage
Hydraulic System 4-2
Lubrication 4-2
Maintenance 4-6
Maintenance Locator Chart
Maintenance Record 4-12
Model and Serial Number
Moving the Mower with Stalled Engine
Mower Blade Maintenance 4-6

PAGE

### PAGE

EN

Mower Blade Maintenance Precautions 2-5
Mower Blades 4-6
Mower Operation
New Season Preparation 6-1
Operating Suggestions 3-9
Operation 2-2
Parts and Service 1-2
Personal Safety 2-1
Preparation of Battery for Storage
Preparation of Engine for Storage
Raising the Deck to the Service Position
Safe Operating Practices2-1, 3-1
Safe Operation 2-1
Safe Servicing Practices 4-1
Safety and Instructions Decals 2-6
Safety Start Interlock System 3-2
Seat Adjustment 4-7
Service Introduction 4-1
Service Precautions 2-4
Slope Guide 2-11
Slope Operation 2-3
Steering Control Lever Adjustment 4-8
Stopping the Engine
System Fuses 4-2
Tires 4-1
To the New Owner
Torque Values 4-1
Using a Ramp 2-3
Using this Manual
Warranty Registration1-1

I-1

EN